



Panel: EVA-Human Modeling

Near-term applications, needs, and challenges of Human-Suit modeling capabilities to inform xEMU development


18 October, 2017

Moderator: Andrew Abercromby

Panel: EVA Human Modeling



- Panel Topic Description
- Panelist Presentations
- Q & A / Discussion
- Wrap-Up



Andrew Abercromby	Lead – EVA Physiology Lab
Richard Rhodes	Space Suit Engineer, Advanced Space Suit Team
Bob Sanders	Medical Director, Neutral Buoyancy Laboratory
Han Kim	Human Factors Design Engineer, Anthropometry & Biomechanics Facility
Leia Stirling	Professor & Co-Director, MIT Man-Vehicle Lab

Panel: EVA Human Modeling



- *Topic Title: Near-term applications and needs of Human-Suit modeling capabilities to inform xEMU development.*
 - Focus on near-term applications of existing models rather than what we could do with better models 5-10 years from now.
 - Are our current models good enough to be helpful? Or do their limitations make them misleading?
 - What EVA-Human models do you already use, if any? What works and what doesn't work?
 - If models are not already being used, why not?
 - What are potential applications of model(s) to xEMU development if they are not already being used? What questions / problems can they address, how soon, and are these actually important problems?





Suit Engineering & Modeling

RICHARD RHODES – SPACESUIT ENGINEER
ADVANCED SPACESUIT DEVELOPMENT TEAM



Background



- ▶ Engineering Goal: Enable crew to perform EVA required tasks with the least amount of energy expenditure
 - ▶ If no specific tasks are identified, maximize mobility with a goal of achieving unsuited performance
- ▶ Mobility is a combination of:
 - ▶ Range of motion
 - ▶ Work or joint torque throughout that range of motion
 - ▶ Natural movement (programming)
- ▶ Mobility is also heavily impacted by fit
 - ▶ Fit is usually evaluated by how well the suit's mobility joints line up with the crew's joints throughout the required tasks



Testing Limitations



- ▶ Development budgets usually do not allow multiple sizes of suits
 - ▶ Consistent subject fit and performance can be a challenge when evaluating suit architectures
 - ▶ Iterations of joint design are expensive and slow
 - ▶ Poor concept or just poor implementation
- ▶ Modeling suit fit and mobility offers a way of evaluating fit, range of motion, and natural movement of mobility architectures without building a fleet of suits
 - ▶ Models need to be validated, but can help guide development
- ▶ Examples of modeling efforts
 - ▶ Fit for Z-2 development




Past Sizing Method



► Historical Sizing method (Mark III & EMU)

- Identify population to fit
- Identify locations on the suit that correspond to the critical anthropometric dimensions
- Validate measurements by building a mockup structure and fit checking crew population
- Results:
 - 2D measurements offer little guidance on sizing of population
 - Fit checking crew population ensures current astronauts will fit, but is not very predictive of future sizes




Recent Modeling Based Sizing



► Z-2 Sizing Method

- Identify population to fit
- Obtain boundary manikins/scans to represent population
- Conduct fit checks of manikins from entire population set in various positions
- 3D print HUT structure and validate model results with subject fit checks
- Results:
 - Offers better evaluation of 3D body shapes
 - Once validated, can easily fit check entire population size ranges
 - By evaluating multiple arm positions, we can evaluate good joint placement and sizes



Future Needs



► Fit – Custom or Fleet Sizing

- Modeling analysis to produce a predicted optimal fit for custom sizing
- Modeling analysis to produce the best sizing across a fleet of suits and the number of suits
 - Combined with mobility analysis to predict mobility when not in optimal fit

► Mobility

- Analysis of current mobility architecture to understand what aspects of the mobility architecture or joints could be improved to offer most natural movement or most efficient interaction with crew
 - Joint angle and position
 - Joint sizing and subject indexing
 - Bearing torque





The EMU vs. The Astronaut



Exposure Incidence System (EIS) Then and Now

Tracking the Human-Suit Interface

Robert W. Sanders, MD, FACEP, FUHM

NBL Medical Director (NASA-JSC)

Assistant Professor

University of Texas Medical Branch, Galveston



The Problem

- Over the years we have identified several significant injuries
 - Shoulder injuries (Slap, rotator cuff)
 - Knee injuries (meniscal tears)
 - Fingernail Delamination
 - What else?





Document to Prevent



- EIS

dev-mmis.ndc.nasa.gov

All records maintained on individuals are protected under the rules set forth in the Privacy Act of 1974. All data viewed in this application is protected by this privacy act along with the HIPAA guideline.

APPLICATION IN SYSTEM TESTING

Welcome NDCInwards11

Exercise Injury System

Home Admin ASCR NBL Doctor

NBL Home Exposures Dive Profiles Conditions Divers Manage Selection Lists

Create NBL Exposure

Diver
 ☐ Include Inactive

Event Date

Exposure Duration (hh:mm)

Comments

B *I* U

g

Characters: 3

Total Inverted Time (hh:mm)

Hut Type
☐ Pivoted ☐ Planar

Wrist Bearing Type
☐ Aluminum ☐ Steel

Shoulder Harness Used
☐ True ☐ False

Shoulder Pads Used
☐ True ☐ False

Used Teflon Inserts
☐ True ☐ False

Locations Iced
☐ Right Shoulder
☐ Left Shoulder
☐ Deferred

[Back to List](#)

[Leave Feedback](#)



Sometimes We Fail





EIS



- We have learned a lot
 - Shoulder injury prevention
 - ASCR Conditioning
 - Inverted Ops
 - Minimize repeated failed attempts
- But learned from injury
 - Attributed to the suit



EIS 2.0



- Desire to learn more about the “pre-exposure” subject (vs. suit)
 - Prone to injury?
 - Sleep?
 - Hydration?
 - Activity level and type
 - Are they ready/fit?
 - Preexisting injury?

The screenshot displays the 'Exposure Incident System 4.0' web application. The interface includes a navigation bar with tabs for 'Actions', 'NDC Database', 'Historical Dive Profiles', 'Conditions', 'Subjects', and 'Manage Selection List'. The main content area is titled 'Dive Exposure - Astronaut X' and features a series of tabs: 'Pre-Built Exposure', 'Pre-Built Diving', 'During Built Exposure', 'Post-Built Exposure', 'Follow Up', 'Issues', and 'Conditions'. The 'Pre-Built Exposure' tab is active, showing a form with the following fields:

- Date and Time (MM/DD/YYYY HH:MM):** 7/15/2024 10:07
- Subject:** Astronaut - Unassigned
- Mission:**
- Exposure Type:** NDC EVA Training
- Location Of Exposure:** NDC
- NDC Run Time:** CB EVA Probe (Rev. 3) PC SPDM LUGB44
- TD, P, Tank Content Percent:** Hardware
- Suit Type:** GML - Mars
- Suit Engineer:** Roger Chalmers
- HUT Name:** NDC
- Off-Nominal:** Not Assigned
- Shoulder Protection Used:** Hardware
- Glove Used:** Phase V
- Waist Bearing Used:** Astronaut
- LTA Used:** GML LTA
- Boot Used:** GML Boot
- Pressure Used:** 4.0-4.5 PSI

At the bottom of the form, there are two buttons: 'Pre-Built Exposure' and 'Back to List'.



EIS 2.0



Create Sanders, Robert W. USO-SD3|WYLLIE LABORATORIES... Details 401 - Unauthorized. Access is denied due to invalid...

All records maintained in this system are protected under the rules set forth in the Privacy Act of 1974. All data viewed in this application is protected by the privacy act along with the HRPAA guidelines.

Exposure Incident System 4.0 Home NBL Doctor

Welcome NDCurwensander!
[Leave Feedback](#)

[NBL Home](#) [NBL Exposure](#) [Exposure Data Profiles](#) [Conditions](#) [Subjects](#) [Manage Association Lists](#)

Dive Exposure - Astronaut X

[Pre-Suited Exposure](#) [Pre-Suit Donning](#) [During Suited Exposure](#) [Post Suited Exposure](#) [Follow Up](#) [Issues](#) [Conditions](#)

[Edit Pre-Suited Exposure](#) [Back to List](#)

Date and Time (MM/DD/YYYY hh:mm):
7/15/2024 15:07

Subject:
Astronaut - UnAssigned

Mission:

Exposure Type:
NBL EVA Training

Location Of Exposure:
NBL

NBL Run Title:
CB EVA Hired Flex (B1C SPOM LUBE4)

TD, PI, Task Contact Person:
Frankie

Suit Type:
EMU - Planar

Suit Engineer:
Roger Graham

HUT Size:
Med

OFF-Nominal:
Not Answered

Shoulder Protection Used:
Harness

Glove Used:
Phase V

Wrist Bearing Used:
Aluminum

LTA Used:
EMU LTA

Boot Used:
EMU Boot

Pressures Used:
4.0-4.3 PSI

[Edit Pre-Suited Exposure](#) [Back to List](#)



EIS 2.0



Create

mmis.ndc.nasa.gov

401 - Unauthorized. Access is denied due to invalid...

Exposure Incident System 4.0

Home

NBL

NBL Home

NBL Exposure

Historical Dive Profiles

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Subjects

Manage Reaction Logs

Welcome NDC/nwsander!

Logout Feedback

Dive Exposure - Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Follow Up

Issues

Conditions

Edit Pre-Suited Exposure

Back to List

Date and Time (MM/DD/YYYY hh:mm):

7/15/2024 15:07

Subject:

Astronaut - UnAssigned

Mission:

Exposure Type:

NBL EVA Training

Location Of Exposure:

NBL

NBL Run Time:

CB EVA Hired Max (BMC SPOM LUBE44)

TD, PI, Task Contact Person:

Frankie

Suit Type:

EMU - Planar

Suit Engineer:

Roger Graham

HUT Size:

Med

OFF-Nominal:

Not Answered

Shoulder Protection Used:

Harness

Glove Used:

Phase V

Wrist Bearing Used:

Aluminum

LTA Used:

EMU LTA

Boot Used:

EMU Boot

Pressures Used:

4.0-4.3 PSI

Edit Pre-Suited Exposure

Back to List

Dive Exposure - Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Follow Up

Issues

Conditions

Edit Pre-Suit Donning

Back to List

Are you hydrated?

Yes

Are you fed?

Yes

Can you clear your ears?

Yes

Are your sinuses clear?

Yes

Did you get sufficient sleep last night?

Yes

Total hours of sleep (hours):

7.5

Do you have any pain, discomfort, or injuries to report prior to donning the suit?

No

Do you participate in any leisure time or ASCR prescribed physical activity?

Not Answered

Exercises

Type	Frequency	Intensity	Duration
Cycling	1-2 times per week	Vigorous	45-60 minutes
Functional Fitness	1-2 times per week	Vigorous	45-60 minutes
Running/Jogging	1-2 times per week	Vigorous	45-60 minutes
Swimming	1-2 times per week	Vigorous	45-60 minutes

Other Activities:

Pre-exposure intervention therapies used:

- Non-Prescription Medications (e.g. Ibuprofen)
- NBL Hardener

Other pre-exposure intervention therapies:

Indicate all other countermeasures (e.g., padding, moleskin, etc.):

Change in countermeasures was only for this suit exposure

Not Answered

Edit Pre-Suit Donning

Back to List



EIS 2.0



Create

At records view

Exposure Incident System 4.0

Home

NBL

NBL Home

NBL Exposure

Historical Dive Profiles

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Follow Up

Issues

Conditions

Edit Pre-Suited Exposure

Back to List

Date and Time (MM/DD/YYYY hh:mm):
7/15/2024 15:07

Subject:
Astronaut - UnAssigned

Mission:
NBL EVA Training

Exposure Type:
NBL EVA Training

Location Of Exposure:
NBL

NBL Run Time:
CB EVA Hired Max (BMC SPOM LUBE4)

TD, PI, Task Contact Person:
Frankie

Suit Type:
EMU - Planar

Suit Engineer:
Roger Graham

HUT Size:
Med

OFF-Nominal:
Not Answered

Shoulder Protection Used:
Harness

Glove Used:
Phase V

Wrist Bearing Used:
Aluminum

LTA Used:
EMU LTA

Boot Used:
EMU Boot

Pressures Used:
4.0-4.3 PSI

Edit Pre-Suited Exposure

Back to List

Create

Sanders, Rob

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Rules

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Edit Pre-Suit Donning

Back to List

Are you hydrated?
Yes

Are you fed?
Yes

Can you clear your ears?
Yes

Are your sinuses clear?
Yes

Did you get sufficient sleep last night?
Yes

Total hours of sleep (hours):
7.5

Do you have any pain, discomfort, or injuries to report prior to donning?
No

Do you participate in any leisure time or ASCR prescribed physical acti
Not Answered

Exercises

Type		
Cycling		1
Functional Fitness		1
Running/Jogging		1
Swimming		1

Other Activities:

Pre-exposure intervention therapies used:

- Non-Prescription Medications (e.g. Ibuprofen)
- NBL Hardener

Other pre-exposure intervention therapies:

Indicate all other countermeasures (e.g., padding, mo'le skin, etc.):

Change in countermeasures was only for this suit exposure
Not Answered

Edit Pre-Suit Donning

Back to List

Create

Sanders, Robert W. (JSC-6031WYL)

Details

401 - Unauthorized: Access is de...

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Rules

Manage Rotation (1/0)

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Follow Up

Issues

Conditions

Edit Post-Suit Exposure

Back to List

Total Time Suited (hh:mm):
05:45

Number of times HUT donned:
1

Total UNplanned doffing events:
0

For all Don events:
Left Lower Arm: Attached
Right Lower Arm: Attached

For all Doff events:
Left Lower Arm: Attached
Right Lower Arm: Attached

Total Time Pressurized (hh:mm):
05:45

Total Time Inverted (hh:mm):
00:00

Do you have any pain, discomfort, or injuries to report?
Yes

Post-exposure therapies administered:

- Declined

Isot Locations

- Deferred

Other post-exposure therapies:

Are additional countermeasures recommended to be added or removed for subsequent suited events?
Not Answered

Additional Comments

Edit Post-Suit Exposure

Back to List

Audit History



EIS 2.0



Create

mmis.ndc

Exposure Incident System 4.0

Home

NBL

NBL Home

NBL Exposure

Historical Dive Profiles

Create

mmis.ndc

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Subjects

Create

mmis.ndc

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Subjects

Manage Selection Lists

Create

mmis.ndc.nasa.gov

Exposure Incident System 4.0

Home

NBL

Doctor

NBL Home

NBL Exposure

Historical Dive Profiles

Conditions

Subjects

Manage Selection Lists

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Edit Pre-Suited Exposure

Back to List

Date and Time (MM/DD/YYYY hh:mm):
7/15/2024 15:07

Subject:
Astronaut - UnAssigned

Mission:

Exposure Type:
NBL EVA Training

Location Of Exposure:
NBL

NBL Run Time:
CB EVA Hired Rev (BNC SPOM LUBE4)

TD, PI, Task Contact Person:
Pawlicki

Suit Type:
EMU - Planar

Suit Engineer:
Roger Graham

HUT Size:
Med

OFF-Nominal:
Not Answered

Shoulder Protection Used:
Harness

Glove Used:
Phase V

Wrist Bearing Used:
Aluminum

LTA Used:
EMU LTA

Boot Used:
EMU Boot

Pressures Used:
4.0-4.3 PSI

Edit Pre-Suited Exposure

Back to List

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Edit Pre-Suit Donning

Back to List

Are you hydrated?
Yes

Are you fed?
Yes

Can you clear your ears?
Yes

Are your sinuses clear?
Yes

Did you get sufficient sleep last night?
Yes

Total hours of sleep (hours):
7.5

Do you have any pain, discomfort, or injuries to report prior to donning?
No

Do you participate in any leisure time or ASCR prescribed physical activity?
Not Answered

Exercises

Type	Frequency
Cycling	1
Functional Fitness	1
Running/Jogging	1
Swimming	1

Other Activities:

Pre-exposure intervention therapies used:

- Non-Prescription Medications (e.g. Ibuprofen)
- Nail Hardener

Other pre-exposure intervention therapies:

Indicate all other countermeasures (e.g., padding, moleskin, etc.):

Change in countermeasures was only for this suit exposure
Not Answered

Edit Pre-Suit Donning

Back to List

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Edit Post-Suit Exposure

Back to List

Total Time Suited (hh:mm):
05:45

Number of times HUT donned:
1

Total Unplanned doffing events:
0

For all Don events:
Left Lower Arm: Attached
Right Lower Arm: Attached

For all Doff events:
Left Lower Arm: Attached
Right Lower Arm: Attached

Total Time Pressurized (hh:mm):
05:45

Total Time Inverted (hh:mm):
00:00

Do you have any pain, discomfort, or injuries to report?
Yes

Post-exposure therapies administered:

- Declined

Isol Locations:

- Deferred

Other post-exposure therapies:

Are additional countermeasures recommended to be added or removed for subsequent exposures?
Not Answered

Additional Comments

Edit Post-Suit Exposure

Back to List

Dive Exposure -- Astronaut X

Pre-Suited Exposure

Pre-Suit Donning

During Suited Exposure

Post Suited Exposure

Follow Up

Issues

Conditions

Edit Issues

Back to List

Body Location	Time Frame	Pain Scale	Symptoms	Signs	Isol Location	Comments
Left Hand - Finger(s)	During	1	• None	• None	No	Small fingers shaking post-run. "gloves too big - they play my fingers too much."
Right Hand - Finger(s)	During	1	• None	• None	No	Small fingers shaking post-run. "gloves too big - they play my fingers too much."

Audit History



Create

mmis.ndc.nasa.gov

401 - Unauthorized: Access is de...

Exposure Incident System 4.0 Home NBL

NBL Home NBL Exposures Historical Dive Profiles

Dive Exposure - Astronaut X

Pre-Suited Exposure Pre-Suit Donning Quit

Edit Pre-Suited Exposure Back to List

Date and Time (MM/DD/YYYY hh:mm):
7/15/2024 15:07

Subject:
Astronaut - Unassigned

Mission:

Exposure Type:
NBL EVA Training

Location Of Exposure:
NBL

NBL Run Time:
CB EVA Hired New (BNC SPOM LUBE4)

TD, PI, Task Contact Person:
Frankie

Suit Type:
EMU - Planar

Suit Engineer:
Roger Graham

HUT Size:
Med

OFF-Nominal:
Not Answered

Shoulder Protection Used:
Harness

Glove Used:
Phase V

Wrist Bearing Used:
Aluminum

LTA Used:
EMU LTA

Boot Used:
EMU Boot

Pressures Used:
4.0-4.3 PSI

Edit Pre-Suited Exposure Back to List

Pre-Suited Exposure Pre-

Edit Pre-Suit Donning

Are you hydrated?
Yes

Are you fed?
Yes

Can you clear your ears?
Yes

Are your sinuses clear?
Yes

Did you get sufficient sleep last
Yes

Total hours of sleep (hours):
7.5

Do you have any pain, discomfort
No

Do you participate in any leisure
Not Answered

Exercises
Type
Cycling
Functional Fitness
Running/Jogging
Swimming

Other Activities:
Pre-exposure intervention ther
• Non-Prescription Medication
• NBL Hardener
Other pre-exposure interventi
Indicate all other countermeasures
Change in countermeasures w
Not Answered

Edit Pre-Suit Donning

Create Sanders, Robert W. (J5C-SD3)[WYL... NBL Home 401 - Unauthorized: Access is de...

Exposure Incident System 4.0 Home NBL Doctor

Welcome NDC\rsander1!
Leave Feedback

NBL Home NBL Exposures Historical Dive Profiles Conditions Subjects Manage Selection Lists

Common Activities

Create Dive Exposure Create 1G Exposure

Recent NBL Exposures

	Full Name	Exposure Date	Event Description	Lab	Location of Exposure	Suit Used	LTA Used	Conditions	Actions
Details			1G - NBLWet	NBL EVA/ISS Procedure Development	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA/ISS Procedure Development	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G -	Mission Training		EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	EMU - Planar	EMU LTA	0	Add Condition
Details			1G - NBLWet	NBL EVA Training	NBL	Z-2	EMU LTA	0	Add Condition

Latest NBL Exposures Resulting in a Condition Report

	Subject	Date	Event Description	Condition
Exposure Condition			1G - NBLWet	Bilateral thumb pain 2/2 glove fit issues and "break points" got to point where GM preferred to truncate run, and requested pain meds
Exposure Condition			1G - NBLWet	Subconjunctival Hematoma noted after run possibly due to inverted time
Exposure Condition			1G - NBLWet	after the run, the patient complains of pain over her left shoulder, especially in the deltoid region. Patient states throughout the run. She felt



55a.gov

Details 401 - Unauthorized: Access is de...

data viewed in this application is protected by this privacy act along with the HIPAA guideline.

Welcome NDC\rsander1!
Leave Feedback

Exposure List

Exposure Follow Up Issues Conditions

Signs	Local Location	Comments
• None	No	Small fingers shaking post-run. "gloves too big - they rub my fingers too much."
• None	No	Small fingers shaking post-run. "gloves too big - they rub my fingers too much."



Still just learning from mistakes...

- Modeling can *prevent* the need to learn from “mistakes”
 - Proactive
 - Prevent or Decrease injuries
 - New Suit Design – Injury ***prevention***
 - No Need to expose personnel to suit to learn



Modeling is a Solid Answer

- What we know is from EMU in NBL
 - vetted in microgravity.
 -
- No new injury patterns "discovered" in space,
 - our process is "working"
- Imagine the benefit to modeling the suit-human interface...
 - to guide suit use and astronaut training in preventive measures without ever having to injure a crew member
 - For planetary missions, there is no equivalent analog... modeling is our only option



Thank You!

- *There is no perfect suit... There is no perfect human, but with the proper modeling, we may create the ideal human-suit interface ... with virtually all injuries made a thing of the past!*





Virtual Fit Check: Parametric Human Body and Suit Models

EVA Technology Workshop 2017

October 17, 2017


Han Kim (Leidos)

NASA JSC Anthropometry & Biomechanics Facility

Predictive Suit Fit Check: Former Techniques



- Linear Measurement Based Technique
 - Compare linear dimensions between suit and crewmembers
 - However, linear measurements do not represent 3-D body and suit geometry



- 3-D Scan Technique
 - Overlay 3-D body scans with CAD drawing to assess overlap and clearance
 - However, scans do not represent the entire ranges of crewmember body shapes




Boundary Subject Sampling




- Body dimensions were strategically sampled to include 99% of population (“boundary subjects”)
- Formerly used a nearest-neighbor scan data, but at present using a parametric body shape model

Identification of Boundary Subjects








Parametric Body Shape Modeling



Boundary Manikin Family



Model-Generated Boundary Manikins (account for 99% of population variation)





Virtual Suit Fit Check:

- Overlay with suit CAD drawings
- Estimation of overlap

Fit Check Techniques for Large Dataset




- *Manual* fit assessments become extremely difficult with a large number of suits and body poses




18 manikins x 3 suit sizes x 3 poses = 162 tests per iteration

- *Programmatic* techniques were developed to automatize suit positioning and clearance quantification
- A reusable manikin was developed to articulate upper extremity poses



Programmatic
Suit Positioning



Automatic
Clearance Quantification




Parametrically
Reusable Manikins

Monte-Carlo Suit Fit Assessment




- A large dataset of body shapes will be generated by a parametric model
- Programmatic suit positioning and volumetric assessment applied to models
- All permutations of suit sizes and body poses will be tested for fit assessments




Future Work: Incorporation with Parametric Suit Modeling



- Previous suit fit check required a end-product CAD or 3-D scan of suit
- In the near future, suit geometry will be parametrically modeled from suit scans
- Suit fit can be predictively assessed for variations of suit configuration and body shape parameters





Han Kim han.kim@nasa.gov

Sudhakar Rajulu sudhakar.rajulu-1@nasa.gov

Work performed in collaboration with:

Elizabeth Benson (MEI Technologies)

Karen Young (Leidos)

Yaritza Bernal (Geologics)

Linh Vu (Geologics)

Decision Support Using an Integrated Human-Exosuit Computational Model Framework

Leia Stirling, PhD

Charles Stark Draper Professor of Aeronautics and Astronautics
Associate Faculty, Institute for Medical Engineering and Science
Massachusetts Institute of Technology

October 18, 2017



Stirling Group Research Goals

Advancing the use of **wearable sensors** in **naturalistic settings** to enable new insights on the interactions between **human motor and cognitive performance**

- Quantifying and modeling human biomechanics during operational tasks
- Mapping complex physiological signals to performance metrics
- Assessing how exosystem design parameters influence motor and cognitive performance



NASA





Occupational Therapy Schools USA



Lockheed Martin

Current Limitations in Modeling Human-Suit Interaction


- Dynamic Interaction Locations
 - Tools exist for gait and ergonomics, as well as mechanical design
 - No software to allow for design of systems with dynamic interaction locations with the human
- Enabling Natural Range of Motion
 - Natural range is not always enabled in spacesuits
 - Increasing hip circumduction during gait without the spacesuit increases required energy (Shorter, Wu, & Kuo, 2017)
 - Motor limitations can influence cognitive elements of performance (Bequette & Stirling pilot data)



Cowley et al., 2012

Our EVA-Human Modeling Approach

- Integrate solid modeling, solid mechanics, and musculoskeletal modeling
- Use the relevant pipeline components to assess decisions related to
 - Kinematic fit (static and dynamic)
 - Assessment of sizes required for a population
 - Dynamics of motion for operational tasks
 - Human energy requirements for operational tasks
 - Potential injury mechanisms




Current Capabilities Examples: Insights from Solid Models



- Informing decisions on locking out joints or placement of bearings
 - Example: The waist bearing range of motion enables a reduced dynamic base during locomotion.

	Static Base (m)	Dynamic Base (m)
Unsuited (Measured)	0.263	0.081±0.021
Suited Walking Forward (Measured)	0.355	0.190±0.027
Suited Walking Forward (Model Minimum)	0.354	

Cullinane, Rhodes, & Stirling L, 2017



- Estimating required torques to generate motion or motion from applied torques
 - Example: Validating model dynamics and assessing the contribution of torque to speed and knee alignments



Cullinane, Rhodes, & Stirling L, In Prep

Example Questions for xEMU Needs

- Range of motion requirements
 - How does including bearings and adapting bearing alignment affect range of motion?
 - How does the natural range of motion compare to the designed range of motion?
- Dynamics of motion for operational tasks
 - What joint torques are required for operationally relevant tasks?
- Considerations in fleet sizing
 - How does selecting a fixed number of sizes affect the fit for a range of anthropometries?
 - What is the lag between human motion and suit motion (i.e., what is the slop)?
 - How does a particular astronaut fit the suit and what indexing would be required?

Acknowledgements

- Research Team
 - Faculty: Leia Stirling (PI), Raul Radovitzky (Co-PI)
 - Students: Conor Cullinane, Chris King, Aditi Gupta, Patrick McKeen
 - Collaborators: Richard Rhodes (NASA), Shane Jacobs (David Clark Company, Inc.), Dennis Anderson (BIDMC)
- The work presented in this presentation has been supported by NASA (NNX15AR20G and NNX15AP51H).

Panel: EVA Human Modeling



- *Topic Title: Near-term applications and needs of Human-Suit modeling capabilities to inform xEMU development.*
 - Focus on near-term applications of existing models rather than what we could do with better models 5-10 years from now.
 - Are our current models good enough to be helpful? Or do their limitations make them misleading?
 - What EVA-Human models do you already use, if any? What works and what doesn't work?
 - If models are not already being used, why not?
 - What are potential applications of model(s) to xEMU development if they are not already being used? What questions / problems can they address, how soon, and are these actually important problems?

